


# Assembly Instruction

MODEL:TORQUE EXT 1604-EXDT


## STEP 1





**Caution:** Do not lift the table top or table by the ceramic glass top during assembly or after assembly. Doing so may cause irreparable damage to the table.

The top and table must only be moved by holding the metal frame under the ceramic glass top.



## STEP 2



D	Ø8		6
C	Ø8		6
B	M8x20		6
A	5mm		1
NO.	SIZE	DIAGRAM	QTY